



Point after barricading to expose pipe.



Exposed pipe showing course of spill.



Point after repair.