



Point before excavation.



Point after excavation and pipeline exposed.



Point after welding.



Point after rapping ready for backfilling.