

SOME PHOTOGRAPHS;



Spill point before excavation.



Point boomed before excavation.



Pipeline exposed showing nipple installed



Spilled point after coning.



Point backfilled after repair.